

# SAE

Alcalá Bauza M., Araujo Rodríguez H., Font  
Sala L., Guzmán Alá A.





# Index



Swimming Analysis Equipment

- ❖ Description of SAE
- ❖ SAE technology
- ❖ Description of the operation and modes of the SAE
- ❖ Development of the software
- ❖ Instructions and usage
- ❖ Applicable regulation
- ❖ Quality control
- ❖ Risk Analysis
- ❖ What do we expect from the future
- ❖ References

## Presentation of the group



**Maite Alcalá:**  
CEO and Regulatory  
director



**Helena Araujo:**  
Director of quality  
control and risks



**Laia Font:**  
Marketing and logistics  
director



**Adalid Guzmán:**  
Technical departament



## Description of SAE



Swimming Analysis Equipment



Figure 1: Swimmer using SAE



Figure 2: SAE presentation

Figure x:



## Description of SAE : Measurement

Acceleration




Figure 3: Coordinate system of SAE [1]

Direction




Figure 4: Active forces while swimming

Force




Figure 5: Diagram of forces present in Front Crawl. Profile view





Figure 6: D. of forces present in Front Crawl. Frontal view



Swimming Analysis Equipment

# SAE TECHNOLOGY




**Video 1:** Components of SAE in exploded view



Swimming Analysis Equipment

## SAE TECHNOLOGY



**Figure 7:** Main electronic components of SAE




## SAE TECHNOLOGY



### IMU

- 3 acceleration channels, 3 angular channels and 3 magnetic field channels
  - Data output: 16-bit
  - Embedded FIFO
  - “Always-on” eco power mode 1.9 mA
  - $\pm 2/\pm 4/\pm 8/\pm 16$  g linear acc. full scale
  - $\pm 4/\pm 8/\pm 12/\pm 16$  gauss magc. full scale
  - $\pm 245/\pm 500/\pm 2000$  dps ang. rate full scale
- [2]



**Figure 8:** LSM9DS1 iNEMO, inertial module: 3D accelerometer, 3D gyroscope, 3D magnetometer/STMicroelectronics







# SAE TECHNOLOGY



## MICROCONTROLLER

- Power supply : 1.8 to 3.6 V
- Temperature range : -40 to 85 °C
- Core : 32bit
- 10 nA ultra-low I/O leakage
- Memory : 128Kbytes of flash, 10kBytes of RAM. [3]



**Figure 9:** STM32L100R8/ STMicroelectronics





# SAE TECHNOLOGY

## BATTERY

- Supply voltage : 3.8V
- Charge voltage : 4.35V
- Capacity : 55mAh
- Dimensions : 20x12x3 mm
- Weight : 1.9g
- Saving battery : no display, ultra-low-power components [4]



Swimming Analysis Equipment



Figure 10: AUCOPO 301220/ AUCOPO

**AUCOPO** 万宝能源

# Description of the operation and mode/s of the SAE




Figure 11: SAE

## POWER BUTTON

- Short press: **turn on**
- Long press: **turn off**

## Battery LED:

- Green: **up to 20% of the charge**
- Red: **less than 20% of battery**

## Recording LED:

- Static light: **device turned on**
- Fast flashing: **calibrating**
- Slow flashing: **recording**

## RECORDING BUTTON


- Short press: **start recording**
- Long press: **calibration**



## Description of the software



Swimming Analysis Equipment




**Diagram 1:** Description of the software




## Description of the software



Swimming Analysis Equipment



**Figure 12:** Gyroscope Navigation frame to Body frame



**Figure 13:** Body Coordinate System: axis and angles



# Instructions and Usage

[www.swimminganalysisequipment.com](http://www.swimminganalysisequipment.com)

**SIGN IN**

Email address


Password


[Submit](#)

SAE INSTRUCTIONS TRANSFER DATA ANALYSIS HISTORIAL

- PROFILE
- PRODUCT REFERENCE
- MY SAE OBJECTIVES ▶
- FACTS
- HELP

▼ FEMALE





Swimming Analysis Equipment

HEIGHT

▼ 167 cm

WEIGHT

▼ 61 Kg

BMI

▼

PERSONAL RECORDS

50 m	▼
100 m	▼
500 m	▼

OBJECTIVES

▼
▼
▼

ANALYSER

OBSERVATIONS

Figures 14,15: Swimming analysis software log in and objectives



# Software and Analysis



Swimming Analysis Equipment





Figure 16: SAS graphics presentation

## Instructions and Usage



**Figures 17:** Position when calibrating SAE and its buttons





## Applicable regulation



UNE-EN 60601-1 for basic Safety and Performance requirements for electromedical equipment.

### MUST PROVE

- Safety
- Electromagnetic compatibility
- Contact to water
- Temperature and humidity environment
- Biocompatibility



## Quality Control



Swimming Analysis Equipment

### Quality control tests:

- Test in normal pool
- Testing in a salt water pool
- Immersion test with the device
- Water jet test
- Movement capture test
  - Dry test
  - Pool test
- Electromagnetic compatibility test



**Figure 18:** Data Capture



## Quality Control

***Quality in manufacturing*** ➡ Product design must receive a rigorous quality review and engineering readiness before it is released into production

***Quality of end device*** ➡ All the failure modes that may occur with products that are defective from the factory and / or possible failures that users purchasing the product have will be taken into account when creating next product batches in order to improve the quality of this and increase its useful life.

# Risk Analysis: Evaluation of probability and severity

Probability of risk	Description
6- Always	Always happens
5-Frequent	$\geq 10^{-3}$
4- Probable	$< 10^{-3}$ and $\geq 10^{-4}$
3- Occasional	$< 10^{-4}$ and $\geq 10^{-5}$
2-Remote	$< 10^{-5}$ and $\geq 10^{-6}$
1-Improbable	$< 10^{-6}$
0-None Observed	Never happens

**Table 1: Probability**

Severity of the Harm	Description
5-Catastrophic	Results in patient death
4- Critical	Results in permanent impairment or life threatening injury
3- Serious	Results in injury or impairment requiring professional medical intervention
2-Minor	Results in temporary injury or impairment not requiring professional medical intervention
1-Negligible	Inconvenience or temporary discomfort

**Table 2: Severity**

# Risk Analysis: FMEA I



Swimming Analysis Equipment

OPERATION	FUNCTION	FAILURE			INDEX		
		MODE	EFFECT	CAUSE	SEVERITY	PROBABILITY	RISK
Swimming Analysis Equipment	Equipment on the wrist in Front Crawl	Erroneous data transfer. 1a	Incorrect study of your style in crawl	misuse of the equipment, wrong software programming, noises and interferences...	3	2	6
		Equipment instability. 1b	Wrong data capture	Turbulent pool water, poor equipment placement	2	3	9
		Leakage current. 1c	Damage to the swimmer	Breakage of the protective case of the equipment	4	2	8
		Incorrect measurement. 1d	Obtaining incorrect data and inability to assess swimming style	Incorrect positioning of the equipment on the wrist or presence of interference in the measurement	3	3	9

# Risk Analysis: FMEA II



Swimming Analysis Equipment

		Breakage. 1e	Inability to use the equipment again and possibility of damage to the client	Friction of the body with the chest, defective protective box...	3	2	6
	Equipment on the chest in Front Crawl	Incorrect measurement. 2a	Obtaining incorrect data and inability to assess swimming style	Incorrect positioning of the equipment on the chest	2	3	6
		Leakage current. 2b	Damage to the swimmer	Breakage of the protective case of the equipment	5	2	10
		Breakage. 2c	Inability to use the equipment again and possibility of damage to the client	Friction of the body with the chest, defective protective box...	4	2	8
	Hand held measuring equipment	Incorrect measurement. 3a	Obtaining incorrect data and inability to assess swimming style	Incorrect positioning of the equipment	3	4	12
		Breakage. 3b	Inability to use the	the equipment	4	4	16

# Risk Analysis: FMEA III



Swimming Analysis Equipment

			equipment again and possibility of damage to the client	may fall to the bottom of the pool, where the box that surrounds the equipment may break			
		Incorrect output. 4a	The desired information is not obtained	The equipment is not programmed for these uses	3	5	15
	Equipment worn on the chest or wrist in a style of swimming other than swimming or in another sport	Breakage. 4b	Inability to use the equipment again and possibility of damage to the client	Breakage of the elastic band due to friction when using it in areas of the body for which it is not intended or breakage of the protective box due to incorrect use while the Arduino board is unprotected	4	5	20

Table 3: FMEA

## Risk Analysis: Acceptance of the risk




Diagram 2: Acceptance of the risk





## WHAT DO WE EXPECT FROM THE FUTURE

Goals in the future:

- Cover all swimming disciplines
- Measure all parameters in different parts of the body
- Move to other sports



## References

- [1] Fag. 4/ Pag. 700/ Microcomputer-based Acceleration Sensor Device for Sports Biomechanics: “Stroke Evaluation by Using Swimmer’s Wrist Acceleration”/ Y. Ohgl/ doi:  
<https://doi.org/10.1109/ICSENS.2002.1037188>
- [2] Pag. 1/ DatasheetLSM6DS3/  
STMicroelectronics/<https://www.st.com/resource/en/datasheet/lsm6ds3.pdf>
- [3] Pag. 1/ Datasheet STM32L100R8/ STMicroelectronics/  
<https://www.st.com/resource/en/datasheet/stm32l100r8.pdf>
- [4] Aucopo 301220 especifications/ AUCOPO/  
<http://www.aucopo.com/index.php?m=content&c=index&a=lists&catid=100>



# THANKS FOR YOUR ATTENTION



Swimming **Analysis** Equipment